
Raspberry Pi for video monitoring

(Relevant information)


Video monitoring system



Assembled hardware



Main model assembled



Connected to monitor and power supply

Data Management





Assembled Pi w/ SSD


- Videos recorded at 20 FPS as h.264 files on the Raspberry Pi.
- After recording, the Raspberry converts the videos to MP4 format.
- Once converted, the MP4 files are uploaded to a google <u>drive file.</u>
- After upload, the MP4 video is deleted from the Raspberry Pi to free up space.
- Timestamps files are saved separately on the Raspberry Pi as the recorded length may not always be accurate due to the FPS value.

Raspberry camera

- → It records compressed video files, it does not record single frames to a video file.
 - Some frames will be late and/or missed and it is difficult to predict which ones.
- → The camera can be triggered using two pins, one for triggering start/stop of video and a second for triggering frames.
- → <u>Trigger Camera project:</u> System designed for time stamped and triggered video acquisition using Raspberry Pi
 - ◆ For synchronizing frame acquisition with external events


Connection between Raspberry Pi and Pico


- → The connection can be established in three ways:
 - Direct USB-to-USB serial
 - Direct Tx/Rx Pins serial
 - GPIO, UART, I2C and SPI
 - ◆ USB-TTL to Rx/Rx serial



Timing of the frames

→ At 20fps, some frames may arrive late or early, and it can be difficult to predict which ones will deviate.







Run #1 Run #2

Dropped frames

Dropped frames can occur unexpectedly



Run #3 Dropped frames = 1675



Run #4 Dropped frames = 124,1446, 4002, 10427